## STOKE presents

## How to Disassemble and Clean your STTOKE Cup's Lid






1. Remove the lid.

The extended part at the top of the lid will give leverage to help you lift the lid out.




2. Pop the slider out.
Place the back of a teaspoon directly under the hole of the closed slider.
Push as hard as you can to pop the slider out of the lid.
(Do not worry about it breaking; our lids are designed this way to keep it spillproof)



 Wash the lid and slider.
 Use a soft sponge on the lid to avoid scratches.





## 4. Put the slider back in.

Make sure that the slider is facing the right way.

- The rectangle-looking part of the slider should be lined up with the drinking hole, face-down.
- Align the curved part of the slider with the curved part of the indentation.
- Insert one side of the slider into the edge, then push the other side of the slider down to pop it back into the lid.



5. All done! Enjoy your coffee!